



PEG POSITIONS		
1	15mm Back	15mm Up
2	15mm Back	27.5mm Up
3	27.5mm Back	15mm Up
4	27.5mm Back	27.5mm Up

All measurements are in relation to stock foot peg position (0 mm).

1. (L) HEEL GUARD [HG-20L]
3. (L) STEP PLATE [K-H2SXSP-L]
5. SHIFT PEDAL [SPD-CP020]
6. SHIFT ROD 80 (BK) [SRD-80B]
10. FOOT PEG [PEG]
11. FOOT PEG END CAP [ST-002]
12. PEDAL TIP (DELRIN) [ST-001D18]
15. HEX HEAD M6 x 30mm [HBT-M630]
20. SOCKET HEAD M8 x 20mm [SBT-M820] x 3
22. LOW SOCKET HEAD M6 x 20mm [LSBT-M620]
23. BUTTON HEAD M6 x 10mm [BBT-M610] x 2
26. BUTTON HEAD M8 x 40mm [BBT-M840]
27. STUD BOLT M8 x 45mm [STBT-45]
30. FLANGE NUT M8 [FNT-8]
34. ROD END COLLAR 10 (BK) [RDED-CLR10]
36. BASE PLATE COLLAR 5 (20mm) (BK) [BPCLR-5]
37. BASE PLATE COLLAR 5 (30mm) (BK) [BPCLR-5-30] x 2
39. PEG COLLAR 15 [PEGCLR-15]
40. BEARING COLLAR 15 (BK) [PEGBGCLR-15SB]
43. FEMALE ROD END M6 [RDED-F6]
- 46. SWITCH (Stock Kawasaki Part)**
- 49. NUT x 2 (Stock Kawasaki Part)**