


Flat side of **BEARING COLLAR 10** (#10) should face **STEP PLATE** (#1), with the stepped side facing out toward shift pedal bearings.



1. (L) STEP PLATE [K-Z125SP-R]
 2. (R) STEP PLATE [K-Z125SP-R]
 3. SHIFT PEDAL [SPD-0912]
 4. BRAKE PEDAL [BPD-DMBP135b]
 5. SHIFT ROD 90 (BK) [SRD-90B]
 6. BRAKE ROD END ADAPTER M6-8 [BRD-ADPTRM6-8]
 7. FOOT PEG [PEG] x 2
 8. FOOT PEG END CAP [ST-002] x 2
 9. PEDAL TIP (DELRIN) [ST-001D18] x 2
 10. BEARING COLLAR 10(BK) [PEGBGLR-10SB]
 11. ROD END COLLAR 29(BK) [RDED-CLR29]
 12. SOCKET HEAD M6x25mm [SBT-M625]
 13. SOCKET HEAD M6x55mm [SBT-M655]
 14. BUTTON HEAD M6x20mm [BBT-M620] x 2
 15. BUTTON HEAD M8x25mm [BBT-M825]
 16. BUTTON HEAD M8x35mm [BBT-M835]
 17. FLAT HEAD M8x20mm [FBT-M820] x 4
 18. FLAT HEAD M8x30mm [FBT-M830] x 2
 19. HEX HEAD M6x18mm [HBT-M618]
 20. MALE ROD END M6 [RDED-M6] x 2
 21. REVERSE MALE ROD END M6 [RDED-M6L]
 22. JAM NUT M6 [JNT-6] x 2
 23. REVERSE JAM NUT M6 [JNT-6L]
 24. LOCK NUT M6 [LNT-6] x 2
 - 25. NUT (KAWASAKI PART)**
 26. RETURN SPRING 40
- BRAKE LIGHT SWITCH P-1.25 [BSW-125] (NOT PICTURED)

To the star cylinder

