



1. (L) HEEL GUARD [HG-6L]
3. (L) STEP PLATE [D-V418SP-L]
5. (L) BASE PLATE [D-V418BP-L]
7. SHIFT PEDAL [SPD-1199]
8. SHIFT LINK (BK) [D-V418RS-LINK]
9. SHIFT PEDAL SPACER (BK)
10. SHIFT ROD 115mm M6L-M8R
16. FOOT PEG [PEG]
17. FOOT PEG END CAP [ST-002]
18. PEDAL TIP (DELRIN) [ST-001D18]
26. PEG COLLAR 15 [PEGCLR-15]
28. HEX HEAD M6x18mm [HBT-M618]
30. HEX HEAD M8x40mm [HBT-M840]
31. SOCKET HEAD M5x10mm [SBT-M510] x 6
32. SOCKET HEAD M8x15mm [SBT-M815] x 2
33. SOCKET HEAD M8x20mm [SBT-M820]
34. SOCKET HEAD M8x25mm [SBT-M825]
35. LOW SOCKET HEAD M6x20mm [LSBT-M620]
36. BUTTON HEAD M5x10mm [BBT-M510] x 2
41. BUTTON HEAD M8x30mm [BBT-M830]
45. REVERSE JAM NUT M6 [JNT-6L]
46. JAM NUT M8 [JNT-8]
47. FLANGE LOCK NUT M8 [FLNT-8]
48. PEG WASHER M8 [PWS-8]
49. SPLIT WASHER M8 [SWS-8]
51. REVERSE MALE ROD END M6 [RDED-M6L]