



- 2. (R) HEEL GUARD [HG-8R]
- 3. (R) STEP PLATE [S-GSX105SP-L]
- 5. (R) BASE PLATE (BK) [H-65021BP-R]
- 7. BRAKE PEDAL [BPD-BPSS165]
- 10. STAY (BK) [STAY-U060645T8]
- 11. FOOT PEG [PEG]
- 12. FOOT PEG END CAP [ST-002]
- 13. PEDAL TIP (DELRIN) [ST-001D18]
- 14. ROD END COLLAR 29 (BK) [RDED-CLR29]
- 16. BEARING COLLAR 3 (BK) [PEGBGCLR-3SB]
- 17. PEG COLLAR 12 [PEGCLR-12]
- 18. HEX HEAD M5x8mm [HBT-M58]
- 20. HEX HEAD M8x40mm [HBT-M840]
- 21. SOCKET HEAD M6x55mm [SBT-M655]
- 22. NARROW SOCKET HEAD M6x20mm x 2
- 23. LOW SOCKET HEAD M6x20mm [LSBT-M620]
- 24. LOW SOCKET HEAD M8x15mm [LSBT-M815] x 2
- 25. LOW SOCKET HEAD M8x20mm [LSBT-M820] x 2
- 26. BUTTON HEAD M5x20mm [BBT-M520]
- 27. BUTTON HEAD M5x35mm [BBT-M535]
- 28. BUTTON HEAD M6x12mm [BBT-M612] x 2
- 29. BUTTON HEAD M8x30mm [BBT-M830]
- 32. SPLIT WASHER M8 [SWS-8]
- 33. NUT M5 [NUT-5] x 2
- 36. LOCK NUT M6 [LNT-6]
- 38. FEMALE ROD END M6-8 [RDED-F6-8]
- 39. PULL SWITCH STAY 14 [PSTAY-14]
- 40. RETURN SPRING 8-25 [RS-RSP825]

*** STOCK HONDA PARTS:**

- 41. NUT
- 42. PULL SWITCH / SPRING
- 47. MASTER CYLINDER

Raised side of PEG BEARING COLLAR 3(#16) should face out towards the Brake Pedal bearings, with the flat side facing the STEP PLATE(#5).

(BACK SIDE)

