


HONDA MONKEY 125 ('18-'20) REVERSE SHIFT REAR SETS

part# H-MKYRSR

[L]-SIDE



Flat side of **BEARING COLLAR 10** (#15) should face **STEP PLATE** (#4), with the stepped side facing out toward the **SHIFT PEDAL** bearings.

1. (L) HEEL GUARD [HG-31L]
2. (L) BOLT COVER [H-GROM16BCR-L]
4. (L) STEP PLATE [H-GROM16SP-L]
6. SHIFT PEDAL [SPD-SCP70]
7. SHIFT ROD 60(BK) [SRD-60B]
11. FOOT PEG [PEG]
12. FOOT PEG END CAP [ST-002]
13. PEDAL TIP (DELIRIN) [ST-001D18]
15. BEARING COLLAR 10(BK) [PEGBGCLR-10SB]
17. ROD END COLLAR 35(BK) [RDED-CLR35]
19. BASE PLATE COLLAR 5(BK) [BPCLR-5]
20. COLLAR 10-12(BK) [CLR-10-12]
22. PEG COLLAR 15 [PEGCLR-15]
23. SOCKET HEAD M5×10mm [SBT-M510]
25. SOCKET HEAD M6×60mm [SBT-M660]
27. SOCKET HEAD M8×20mm [SBT-M820]
28. SOCKET HEAD M8×45mm [SBT-M845]
30. BUTTON HEAD M6×10mm [BBT-M610] x 2
34. BUTTON HEAD M8×35mm [BBT-M835]
35. LOW SOCKET HEAD M6×20mm [LSBT-M620]
37. HEX HEAD M6×18mm [HBT-M618]
40. JAM NUT M6 [JNT-6]
41. REVERSE JAM NUT M6 [JNT-6L]
42. LOCK NUT M6 [LNT-6]
43. MALE ROD END M6 [RDED-M6]
44. REVERSE MALE ROD END M6 [RDED-M6L]

***46. CHANGE ARM (STOCK HONDA PART)**

***47. WASHER (STOCK HONDA PART)**

Adjust shift arm position

