





(BACK SIDE)



- 2. (R) HEEL GUARD [HG-6R]
- 4. (R) STEP PLATE [K-ZH2SP-R]
- 6. (R) BASE PLATE [K-ZH2BP-R]
- 8. (R) FRAME COVER (BK) [K-ZH2FMCV-R]
- 10. BRAKE PEDAL [BPD-SSBP165]
- 12. FOOT PEG [PEG] x 2
- 13. FOOT PEG END CAP [ST-002] x 2
- 14. PEDAL TIP (DELFIN) [ST-001D18] x 2
- 15. COLLAR 25-6(SV) [CLR-25-6] x 2
- 17. ROD END COLLAR 23(BK) [RDED-CLR23]
- 18. PEG COLLAR 15 [PEGCLR-15]
- 20. SOCKET HEAD M5x10mm [SBT-M510] x 3
- 21. SOCKET HEAD M5x35mm [SBT-M535] x 2
- 22. SOCKET HEAD M6x50mm [SBT-M650]
- 23. SOCKET HEAD M8x15mm [SBT-M815] x 2
- 24. BUTTON HEAD M5x40mm [BBT-M540]
- 25. BUTTON HEAD M6x10mm [BBT-M610] x 2
- 26. BUTTON HEAD M8x20mm [BBT-M820] x 2
- 27. BUTTON HEAD M8x25mm [BBT-M825]
- 29. LOW SOCKET HEAD M6x20mm [LSBT-M620]
- 30. HEX HEAD M5x8mm [HBT-M58]
- 32. HEX HEAD M8x40mm [HBT-M840]
- 33. NUT M5 [NUT-5] x 3
- 35. LOCK NUT M6 [LNT-6]
- 36. SPLIT WASHER M8 [SWS-8]
- 38. FEMALE ROD END 6-M8 [RDED-F6-8]
- 39. PULL SWITCH STAY 16 [PSTAY-16]
- 40. RETURN SPRING 40 [RS-RSP]

*** STOCK KAWASAKI PARTS**
49. PULL SWITCH / SPRING
55. MASTER CYLINDER
56. NUT

♦ Apply threadlocker (Loctite or Vibra Tite or similar) to these bolts before tightening.
 (Factory pre-tightened parts such as the Brake Pedal have already been Loctited.)

∞ Clean and lubricate rod end ball joint periodically.