




[L]



*** STOCK KAWASAKI PARTS:**
37. SHIFTER SWITCH
38. MASTER CYLINDER
39. NUT
40. NUT

[R]



1. (L) HEEL GUARD [HG-2L]
2. (R) HEEL GUARD [HG-2R]
3. (L) STEP PLATE [K-ZX613SP-L]
4. (R) STEP PLATE [Y-R3RC2SP-R]
5. (L) BASE PLATE (BK) [K-ZX25RCBP-LB]
6. (R) BASE PLATE (BK) [K-ZX25RCBP-RB]
7. SHIFT PEDAL [SPD-CPS82R]
8. BRAKE PEDAL [BPD165-30]
9. FOOT PEG [PEG] x 2
10. FOOT PEG END CAP [ST-002] x 2
11. PEDAL TIP (ALUM)(GD) [ST-001RG] x 2
12. RUBBER SLEEVE [ST-001R-SL] x 2
13. SHIFT ROD 60 (BK) [SRD-60B]
14. BEARING COLLAR 5 (BK) [PEGBGCLR-5SB]
15. BEARING COLLAR 15 (BK) [PEGBGCLR-15SB]
16. BRAKE ROD ADAPTER 6-M8 [BRDADPTRM6-8]
17. ROD END COLLAR 5 (BK) [RDED-CLR5]
18. ROD END COLLAR 19 (BK) [RDED-CLR19]
19. PEG COLLAR 12 (GD) [PEGCLR-12] x 2
20. HEX HEAD M6x22mm [HBT-M622]
21. HEX HEAD M8x40mm [HBT-M840] x 2
22. BUTTON HEAD M6x10mm [BBT-M610] x 4
23. BUTTON HEAD M8x30mm [BBT-M830]
24. BUTTON HEAD M8x40mm [BBT-M840]
25. LOW SOCKET HEAD M6x15mm [LSBT-M615] x 2
26. LOW SOCKET HEAD M8x15mm [LSBT-M815] x 4
27. LOW SOCKET HEAD M8x20mm [LSBT-M820] x 6
28. SOCKET HEAD M6x45mm [SBT-M645]
29. REVERSE STUD M6 [STUD-M6L]
30. MALE ROD END M6 [RDED-M6]
31. REVERSE FEMALE ROD END M6 [RDED-F6L]
32. REVERSE JAM NUT M6 [JNT-6L] x 2
33. JAM NUT M6 [JNT-6]
34. LOCK NUT M6 [LNT-6]
35. SPLIT WASHER M8 [SWS-8] x 2
36. RETURN SPRING 40 [RS-RSP]

Cut or replace the fluid hose.

(Back Side)

