



[L]



1. (L) HEEL GUARD [HG-6L]
2. (R) HEEL GUARD [HG-6R]
3. (L) STEP PLATE [K-ZX25SP-L]
4. (R) STEP PLATE [K-ZX25SP-R]
5. MASTER STAY (BK) [K-ZX25MS]
6. SHIFT PEDAL [SPD-SCP80]
7. SHIFT ROD 80 (BK) [SRD-80B]
8. BRAKE PEDAL [BPD-SSBP165]
9. FOOT PEG [PEG] x 2
10. FOOT PEG END CAP [ST-002] x 2
11. PEDAL TIP (DELTRIN) [ST-001D18] x 2
12. ROD END COLLAR 5 (BK) [RDEDCLR-5]
13. ROD END COLLAR 25 (BK) [RDEDCLR-25]
14. BASE PLATE COLLAR 6 (BK) [BPCLR-6] x 4
15. PEG COLLAR 15 [PEGCLR-15] x 2
16. BEARING COLLAR 15 (BK) [PEGBGCLR-15SB]
17. LOW SOCKET HEAD M6 x 20mm [LSBT-M620] x 2
18. LOW SOCKET HEAD M8 x 25mm [LSBT-M825] x 4
19. BUTTON HEAD M6 x 10mm [BBT-M610] x 6
20. BUTTON HEAD M8 x 20mm [BBT-M820] x 2
21. BUTTON HEAD M8 x 25mm [BBT-M825]
22. BUTTON HEAD M8 x 40mm [BBT-M840]
23. SOCKET HEAD M5 x 20mm [SBT-M520]
24. SOCKET HEAD M5 x 45mm [SBT-M545]
25. SOCKET HEAD M6 x 50mm [SBT-M650]
26. STUD BOLT M8 x 50mm [STBT-50] x 2
27. HEX HEAD M5 x 6mm [HBT-M56]
28. HEX HEAD M6 x 22mm [HBT-M622]
29. NUT M5 [NUT-5] x 2
30. LOCK NUT M6 [LNT-6]
31. REVERSE JAM NUT M6 [JNT-6]
32. FLANGE NUT M8 [FNT-8] x 2
33. REVERSE MALE ROD END M6 [RDED-M6L]
34. FEMALE ROD END 6-M8 [RDED-F6-8]
35. RETURN SPRING 8-35 [RS-RSP8-35]
36. PULL SWITCH STAY 16 [PSTAY-16]

*** STOCK KAWASAKI PARTS:**
37. NUT
38. SHIFTER SWITCH
39. PULL SWITCH / SPRING
40. MASTER CYLINDER
41. NUT

[R]



(Back Side)

