



1. HEEL GUARD [L] [HG-6L]
  2. HEEL GUARD [R] [HG-6R]
  3. STEP PLATE [L]
  4. STEP PLATE [R]
  5. SHIFT PEDAL [SPD-0912]
  6. SHIFT ROD 90 [SRD-90]
  7. BRAKE PEDAL [BPD-15]
  8. HANGER BRACKET (BK)
  9. STAY (BK) [STAY-6L45T6]
  10. FOOT PEG END CAP [ST-002] x 2
  11. FOOT PEG [PEG] x 2
  12. PEDAL TIP (DELRIN) [ST-001D18] x 2
  13. BEARING COLLAR 13(BK) [PEGBGCLR-13SB]
  14. ROD END COLLAR 3(GD) [RDED-CLR3]
  15. ROD END COLLAR 23(BK) [RDED-CLR23]
  16. BASE PLATE COLLAR 2(BK) [BPCLR-2] x 4
  17. PEG COLLAR 15 [PEGCLR-15] x 2
  18. SOCKET HEAD M5x10mm [SBT-M510] x 2
  19. SOCKET HEAD M5x40mm [SBT-M540]
  20. SOCKET HEAD M6x20mm [SBT-M620]
  21. SOCKET HEAD M6x50mm [SBT-M650]
  22. SOCKET HEAD M8x20mm [SBT-M820] x 4
  23. BUTTON HEAD M5x15mm [BBT-M515]
  24. BUTTON HEAD M6x10mm [BBT-M610] x 4
  25. BUTTON HEAD M6x20mm [BBT-M620] x 4
  26. BUTTON HEAD M8x25mm [BBT-M825]
  27. BUTTON HEAD M8x35mm [BBT-M835]
  28. HEX BOLT M5x6mm [HBT-M56]
  29. STUD BOLT M8x50mm [STBT-50] x 2
  30. STUD M6 [STUD-M6]
  31. NUT M5 [NUT-5] x 2
  32. JAM NUT M6 [JNT-6] x 2
  33. REVERSE JAM NUT M6 [JNT-6L]
  34. LOCK NUT M6 [LNT-6]
  35. FLANGE LOCK NUT M8S [FLNT-8S] x 2
  36. REVERSE MALE ROD END M6 [RDED-M6L]
  37. FEMALE ROD END 6-M8 [RDED-F6-8]
- SPRING 8-25 (not pictured) [RS-RSP825]

