



1. (L) HEEL GUARD [HG-2L]
2. (R) HEEL GUARD [HG-1R]
3. (L) STEP PLATE [S-SV65016SP-L]
4. (R) STEP PLATE [S-SV65016SP-R]
5. MASTER STAY [S-SV65016MS]
6. SHIFT PEDAL [SPD-80-90]
7. BRAKE PEDAL [BPD-165-30]
8. SHIFT ROD 170 [SRD-170]
9. FOOT PEG [PEG] x 2
10. FOOT PEG END CAP [ST-002] x 2
11. PEDAL TIP (DELRIN) [ST-001D18]
12. PEDAL TIP LONG (DELRIN) [ST-001DL]
13. ROD END COLLAR 3(GD) [RDED-CLR3]
14. ROD END COLLAR 19(BK) [RDED-CLR19]
15. BASE PLATE COLLAR 12(BK) [BPCLR-12] x 2
16. BASE PLATE COLLAR 16(BK) [BPCLR-16] x 2
17. PEG COLLAR 12 [PEGCLR-12] x 2
18. BEARING COLLAR 5(BK) [PEGBGCLR-5SB]
19. SOCKET HEAD M5x15mm [SBT-M515]
20. SOCKET HEAD M5x40mm [SBT-M540]
21. SOCKET HEAD M6x45mm [SBT-M645]
22. SOCKET HEAD M8x30mm [SBT-M830] x 4
23. BUTTON HEAD M6x10mm [BBT-M610] x 2
24. BUTTON HEAD M6x20mm [BBT-M620]
25. BUTTON HEAD M6x25mm [BBT-M625] x 2
26. BUTTON HEAD M6x30mm [BBT-M630]
27. BUTTON HEAD M8x25mm [BBT-M825]
28. BUTTON HEAD M8x30mm [BBT-M830]
29. BUTTON HEAD M6x10mm [BBT-M610] x 2
30. HEX HEAD M5x6mm [HBT-M56]
31. HEX HEAD M6x20mm [HBT-M620]
32. STUD M6 [STUD-M6]
33. STUD BOLT M8x45 [STBT-45] x 2
34. NUT M5 [NUT-5] x 2
35. JAM NUT M6 [JNT-6] x 2
36. REVERSE JAM NUT M6 [JNT-6L]
37. LOCK NUT M6 [LNT-6]
38. FLANGE NUT M8 [FNT-8] x 2
39. SPRING 8-35 [RS-RSP8-35]
40. REVERSE MALE ROD END M6 [RDED-M6L]
41. FEMALE ROD END 6-M8 [RDED-F6-8]
42. PULL SWITCH STAY 16 [PSTAY-16]