


YAMAHA FZ-10 / MT-10/SP ('17-'25) REAR SETS

part# Y-MT10RS


[L]



PEG POSITIONS		
1	17.5mm Back	25mm Up
2	17.5mm Back	37.5mm Up
3	17.5mm Back	50mm Up
4	30mm Back	37.5mm Up
5	30mm Back	50mm Up

All measurements are in relation to stock foot peg position (0 mm).

[R]



1. (L) HEEL GUARD [HG-6L]
2. (R) HEEL GUARD [HG-6R]
3. (L) STEP PLATE [Y-MT10SP-L]
4. (R) STEP PLATE [Y-MT10SP-R]
5. SHIFT PEDAL (BK) [SPD-CP021]
6. SHIFT ROD 110 (BK) [SRD-110B]
7. BRAKE PEDAL [BPD-BPSS165]
8. STAY (BK)
9. CANISTER BRACKET (SV)
10. FOOT PEG [PEG] x 2
11. FOOT PEG END CAP [ST-002] x 2
12. PEDAL TIP (DELFIN) [ST-001D18]
13. PEDAL TIP LONG (DELFIN) [ST-001DL]
14. STUD BOLT M8x50mm [STBT-50] x 2
15. HEX HEAD M5x6mm [HBT-M56]
16. SOCKET HEAD M5x10mm [SBT-M510] x 2
17. SOCKET HEAD M5x15mm [SBT-M515]
18. SOCKET HEAD M5x35mm [SBT-M535]
19. SOCKET HEAD M6x15mm [SBT-M615]
20. SOCKET HEAD M6x18mm [SBT-M618]
21. SOCKET HEAD M6x50mm [SBT-M650]
22. SOCKET HEAD M8x15mm [SBT-M815]
23. SOCKET HEAD M8x20mm [SBT-M820] x 4
24. SOCKET HEAD M8x45mm [SBT-M845]
25. BUTTON HEAD M6x10mm [BBT-M610] x 4
26. BUTTON HEAD M6x20mm [BBT-M620]
27. BUTTON HEAD M6x30mm [BBT-M630]
28. BUTTON HEAD M8x25mm [BBT-M825] x 3
29. COLLAR 23 (BK)
30. BEARING COLLAR 18 [PEGBCLR-18]
31. PEG COLLAR 15 [PEGCLR-15] x 2
32. NUT M5 [NUT-5] x 2
33. REVERSE JAM NUT M6 [JNT-6L]
34. LOCK NUT M6 [LNT-6]
35. FLANGE NUT M8 [FNT-8] x 2
36. REVERSE MALE ROD END M6 [RDED-M6L]
37. FEMALE ROD END 6-M8 [RDED-F6-8]
38. PULL SWITCH STAY 16 [PSTAY-16]
39. RETURN SPRING 8-25 [RS-RSP8-25]

* 40. NUT (YAMAHA part)

* 41. PULL SWITCH (YAMAHA part)

(BACK SIDE)

